




www.arctic.ac



S111 BT

Nánod k použití



support.arctic.ac/S111BT

Dear Customer,


Thank you for choosing the ARCTIC S111 BT.

This compact system is the perfect companion to your smartphone or tablet for on-the-go music enjoyment. An extra large driver-magnet allows us to get the maximum out of these small boxes.

I hope you enjoy the S111 BT and we at ARCTIC look forward to further enriching your life with our products. If you would like to share how you use ARCTIC's products please do so at <https://www.facebook.com/ARCTIC.en>


ARCTIC is a fully carbon neutral company and your support helps us to compensate every kilogram of CO₂ we produce. Thank You.

Sincerely,


Magnus Huber
ARCTIC CEO

Příslušenství


Reproduktory x 1




Obal x 1



3.5mm stereo jack
audio kabel x 1



Micro USB kabel x 1



Návod x 1




Funkce

- ① Zapnuto / Play / Pauza
- ② Ztlumení hlasitosti / Další skladba
- ③ Zesílení hlasitosti / Předchozí skladba
- ④ LED indikátor
- ⑤ Micro-USB
- ⑥ 3.5 mm Audio vstup

Levý reproduktor

Pravý reproduktor



Zapojení / párování



Reproduktory S111 BT lze k mobilním zařízením připojit dvěma rozdílnými způsoby:

A. Propojení pomocí Bluetooth

1. Zapněte S111BT krátkým stisknutím tlačítka power .
2. Reproduktory S111 BT se automaticky nastaví do párovacího módu a začne blikat LED kontrolka (modře / červeně).
3. Zapněte bluetooth na svém mobilním zařízení a spárujte s reproduktory.



Například: iOS

Stiskněte nastavení > Zapněte Bluetooth > Vyberte S111BT > Spárujte



Například: Android 4.0

Vstupte do Menu > Nastavení > Zapněte Bluetooth > Bluetooth > Najděte zařízení > S111BT > Spárujte





Poznámka:

- Režim párování může trvat až pět minut nebo pokud je zařízení nalezeno, zazní dva tóny, které oznámí párování zařízení.
- Účinný dosah bluetooth zařízení je cca. 10m, reproduktor se odpojí a znovu se automaticky připojí během deseti minut, pokud se reproduktor dostane do dosahu signálu.

B. Propojení pomocí kabelu (pro verzi s BT 4.0 omezeno)

1. Zapněte reproduktory S111 BT pomocí vypínače .
2. Vložte jeden konec 3,5mm audio kabelu do reproduktoru a druhý do sluchátkového výstupu svého mobilního zařízení.
3. Přehrávejte hudbu!
4. U verze s Bluetooth 4.0 slouží konektor pro zapojení druhého zdroje hudby.
Zařízení musí být vždy připojeno pomocí Bluetooth!!

LED zobrazení

Pokud jsou S111 BT a je zapojeno nabíjení:

Červená	Nabíjení
Modrá	Nabito

Pokud jsou S111 BT zapnuty:

Modrá a červená bliká	Párovací mód
Modrá	Baterie >75%
Fialová (více modrá)	Baterie ~50%
Fialová bliká	Baterie ~25%

Znovuzapojení

Pomocí Bluetooth

1. Zapněte Bluetooth na telefonu.
2. Pokud váš přístroj byl poslední, který byl spárován s S111 BT opět se automaticky připojí. Jinak krátce stiskněte tlačítko pro napájení .
3. Pokud se S111 BT stále nespárovaly, opakujte znovu párování.

Ovládání hudby

Zapnutí:

Krátce stiskněte tlačítko .

Přidání hlasitosti:

Jednou stiskněte **VOL +**.

Ubrání hlasitosti:

Jednou stiskněte **VOL -**.

Další skladba:

Při přehrávání hudby stiskněte a podržte **VOL +** dokud se nespustí další skladba.

Předchozí skladba:

Při přehrávání hudby stiskněte a podržte **VOL -** dokud se nespustí skladba odznova. Rychle znovu stiskněte a podržte **VOL -** dokud se nespustí předchozí skladba.

Pauza / Přehrát:

Jednou krátce stiskněte .


Vypnutí:

Stiskněte a podržte tlačítko  po dobu 5 sekund.

Nabíjení

S113BT lze nabíjet v zapnutém nebo vypnutém stavu.

1. Zapojte micro USB kabel do S111 BT a stranu s USB zapojte do zdroje napájení.
2. Svítí-li modrá LED dioda je S111 BT plně nabit.



Doporučujeme plně nabít před prvním použitím.

Návrat do továrního nastavení

1. Zapněte S111BT krátkým stisknutím tlačítka power .
2. Stiskněte a držte najednou tlačítka **VOL -** a **VOL +** po dobu 8 sekund.
3. Po 8 sekundách se reproduktory samy automaticky vypnou.

Upozornění

- Bezdrátové připojení bývá ovlivněno překážkami například stěnami.
- Udržujte S111 BT v suchu. Vlhkost může poškodit elektronické součástky.
- Vystavení vysoké teplotě zkrátí životnost výrobku a může poškodit elektronické komponenty.
- Rozebrání / poškození S113 BT má za následek zánik záruky.
- Hrubé zacházení může poškodit vnitřní elektronické součástky.

Záruka

Na tento produkt poskytuje společnost ARCTIC dvouletou omezenou záruku. Více na www.warranty.arctic.ac



FCC ID Z3AS111BT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help



EC Declaration of Conformity

ARCTIC declares under its sole responsibility that this product is compliant with the provisions of the Radio and Telecommunications Terminal Equipment directive (1999/5/EC) and the Restriction of the use of certain hazardous substances directive (2011/65/EU). A detailed Declaration of Conformity is available at <http://s111bt.arctic.ac#support>



Directive 2002/96/EC about Waste of Electrical and Electronic Equipment (WEEE)

Waste of Electrical and Electronic Equipment must not be disposed of with domestic waste.

If the device cannot be used anymore, the user is legally obliged to separate it from domestic waste and hand it over to a designated collection point of his community/district.

Thereby it is guaranteed that the Waste of Electrical and Electronic Equipment is recycled properly and negative impacts for the environment are avoided.

Therefore, electronic devices are marked by this sign.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by ARCTIC (HK) Ltd. is under license. Other trademarks and trade names are those of their respective owners.

ARCTIC and the ARCTIC logo are registered trademarks of Boost Up International Limited.

© 2015 ARCTIC (HK) Ltd. All rights reserved.

No part of this manual including the products described in it, may be reproduced, transmitted, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purpose, without the express written permission of ARCTIC (HK) Ltd. In no event shall ARCTIC, its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.